

## INSTRUCTIONS FOR THE INSTALLATION DPM RECOIL ROD - GLOCK 17L - 34 – 35

**ATTENTION: FIRSTLY FOLLOWS THE  
GENERAL INSTRUCTIONS AND USE  
ALWAYS EYE PROTECTION GLASSES**

1. Use always only one (1) washer with the DPM Recoil Rod (Fig1).



2. Install one spring on the rod and one washer, compress it and insert the safety pin in the small hole of the Rod. (Fig 2). The DPM rod is ready for installation. (Fig1).



Continue 

3. Insert the DPM Rod in the slide hole and press it to click on the correct position of the barrel. (Fig 3).



4. Finally pull out the safety pin and ensure that the DPM rod and the washer are placed in the correct position (Fig 4).



5. Before loading the magazine function (open and close) the slide several times to ensure that the DPM Rod functions unrestricted.

Please follow the instructions when you install the spring and the washer on the rod **and use always eye protection glasses**. For any questions about the installation please contact: [service@dpmsystems.com](mailto:service@dpmsystems.com)